


Dynafluid 2000 - 1.5"



1.5" MIXING VALVE REPAIR KIT P/N: 2000-100-11/2J

INCLUDES: 2000-13-11/2J
2000-53-1/2J
2000-16-11/2J
2000-57-11/2J
2000-58-11/2J
2000-61-1J
2000-63-11/2J

1 1/2" DYNAFLUID VALVE

T&S Part Number	Dynafluid Part Number	New Dynafluid Part Number	Description
012797-45		2000-28-1/2DYNA	NAMEPLATE
005248-45	SPSV0015J		NAMEPLATE
004189-45		2000-51-11/2J	CONTROL KNOB
012766-45		2000-27-1/2J	CONTROL KNOB SCREW
004094-45	769-27-1/2		CONTROL KNOB SCREW
004123-45		2000-53-1/2J	TOP CAP PACKING SET
004192-45		2000-6-11/2J	TOP CAP
012807-45		2000-13-11/2J	TOP CAP GASKET
004196-45		2000-9-11/2J	SPINDLE
004145-45		2000-36-1/2J (2)	CONTROL KNOB STOPS
012813-45		2000-61-1J	COVER SCREWS & WASHERS
004218-45	LISW0023J		COVER SCREWS & WASHERS
012805-45		2000-50-11/2J	COVER ASSEMBLY
004187-45	SPSV0049J		COVER ASSEMBLY
012815-45		2000-62-11/2J	SEALING PLUG & WASHER
004199-45		2000-55-11/2J	INPUT VALVE & PACKING
004198-45		2000-54-11/2J	INPUT STOP & WASHER
004193-45		2000-7A-11/2J	FIXED SPRING 0-50 PSIG
004194-45		2000-7-11/2J	FIXED SPRING 50-100 PSIG
004195-45		2000-7B-11/2J	FIXED SPRING 100-150 PSIG
004169-45		2000-66-11/2J	STEAM VALVE NUT & WASHER
004202-45		2000-57-11/2J	STEAM VALVE & SPRING
004978-45		2000-5-11/2J	UPPER PISTON PLATE & SCREWS
004200-45		2000-16-11/2J	SEAT RETAINER
004201-45		2000-63-11/2J	SEAT WASHERS
004190-45		2000-4-11/2J	SKIRTED PISTON
004203-45		2000-22-11/2J	SLEEVE
012808-45		2000-58-11/2J	COVER TO BASE SEAL
004205-45	SPSV0034J		COVER TO BASE GASKET
012814-45		2000-23-11/2J	RELIEF/LOCATION TUBE
004214-45	770-33-1		RELIEF/LOCATION TUBE
012803-45		2000-1-11/2J	BODY
004184-45	770-1-11/2J		BODY
012810-45		2000-26-11/2J	UNION GASKET
012811-45		2000-60-11/2J	UNION ASSEMBLY
004206-45		2000-59-11/2J	BRACKET AND SCREWS
012817-45		2000-100-11/2J	VALVE REPAIR KIT
004183-45	SPSV0040J		VALVE REPAIR KIT